

AVC783 Hardware Reset

1. Dismount the cover from the unit.
2. see pic
3. After connecting the two jumps to form a short circuit, plug in the power and hold the short circuit more than 10 seconds.

