


Step 1: Remove the DVR cover and find the chip resistor to reset the hardware (next to the Power Board)



Step 2: The chip resistor is located on R288, as indicated below:

