


Hardware Reset Approach for DR040


1. Turn off the power and dismount the cover from the unit.



2. Find the Reset Point.



3. Take a closer look at Reset Point (The 2 pins, JP4 Position).



4. Connect the two jumps (pins) to form a short circuit. Then plug in the power and hold the short circuit for about 30 seconds until appears the initiation image and then DVR will be rebooted after several seconds.

