


Hardware Reset Approach for KPD616


1. Turn off the power and dismount the cover from the unit.



2. Find the Reset Position (BC563)



3. Take a closer look at Reset Position.



4. Use the forceps to connect BC563 to form a short circuit. Then plug in the power and hold the short circuit for about 15 seconds until appears the initiation picture and then DVR will be rebooted after 5 seconds.

